



Fast Fold Camping

Tent Stove



This wood-burning tent Stove simply folds the walls into place, secures them with integrated clasps, and the flue pipe rolls into a compact tube then start to work. It is a good gear for the outdoor cooking and heating, popular with outdoor enthusiasts and backpackers due to its lightweight and ultra-portable.

What's included

1* Fast fold stove body, 1 rolled stove pipe, 1 spark arrestor, 1 carry bag



Specification

NAME	DETAILS
Stove Body	0.8mm Stainless Steel 304, 38*24cm
Chimney	0.1mm Stainless Steel 304, 24*200cm
Chimney damper	Stainless Steel, Dia 6.2cm
Spark Arrestor	Stainless Steel
Fuel shelf	2mm 304 Stainless Steel, 18*16.5cm
Side glass	4mm glass, heat-resistant
Carry bag	Oxford, 42*33cm
Master Box	5 layers, 51*38*12cm

Features



Foldable

One hand can carry it with the bag easily, and finish the fold and plug work in less than 2 mins.



Stainless Steel 304

Quick heat conduction for heating and cooking food without the cookware turned black.



Premium glass window

Heat-resistant and easily to observe the combustion and enjoy the cozy atmosphere that dancing flame brings

Assembling Steps



1. Take out whole stove body



2. Open the stove legs



5. Cover the top plate



4. Insert the side panels



3. Open the front and rear panels

Different package method



1pcs pizza box
Sample



48pcs in one pallet
Trial order



5pcs in one master carton
Bulk order

Cast iron Cookware compatible with the tent stove